



OpenSees

Open System for Earthquake Engineering Simulation
Pacific Earthquake Engineering Research Center



OpenSees & Output


Vesna Terzic
UC Berkeley

November 2011

Agenda

- Introduction to Output options
- OpenSees commands for creating the output: recorder, print, recorder display, commands that return values (e.g., nodeDisp) - demonstrated by examples
- Tcl “puts” commands for creating the output - demonstrated by example
- Summary
- Q & A with web participants

Main Abstractions in OpenSees Framework



Output Options

When you run OpenSees **THERE IS NO OUTPUT PROVIDED
UNLESS YOU REQUEST IT**

The commands for creating the output:

1. **recorder** command

recorder \$type \$arg1 \$arg2 ...

2. **puts** command

puts <\$fileID> \$string

3. **print** command

print <-file \$fileName> <-node \$nd1 \$nd2 ..> <-ele \$ele1 \$ele2 ...>

4. OpenSees commands that return values (e.g., nodeDisp)

5. **recorder display** command

Recorder Command

```
recorder $type $arg1 $arg2 $arg3 ....
```

[http://opensees.berkeley.edu/wiki/index.php/Recorder Command](http://opensees.berkeley.edu/wiki/index.php/Recorder_Command)

Recorder types:

Node:

- Node
- EnvelopeNode
- Drift

Element/section/fiber:

- Element
- EnvelopeElement

Graphics:

- plot

Element/EnvelopeElement Recorders

- To monitor what's happening in the elements/sections/fiber:

```
recorder Element <-file $fileName> <-time> <-ele $tg1 $tg2 ...> $arg1 $arg2 ...  
    <-xml $fileName> <-eleRange $tgS $tgE>  
    <-binary $fileName> <-region $rTag>  
    <-tcp $inetAddr>
```

- The response you can ask vary from element to element. There are arguments that are same for all elements, e.g. forces.

```
recorder Element -file ele.out -ele 1 2 forces
```

- The EnvelopeElement takes exactly same args

```
recorder EnvelopeElement <-file $fileName> <-time> <-ele $tg1 $tg2 ...> $arg1 $arg2 ...  
    <-xml $fileName> <-eleRange $tgS $tgE>  
    <-binary $fileName> <-region $rTag>  
    <-tcp $inetAddr>
```

The valid args for different elements

Elastic BCE:

force

Force BCE and BWHE:

force

globalForce

localForce

basicForce

section \$secTag \$arg1 \$arg2

basicDeformation

plasticDeformation

inflectionPoint

tangentDrift

integrationPoints

integrationWeights

Displacement BCE:

force

section \$secTag \$arg1 \$arg2

The valid args for different elements

ZeroLength Element:

force
deformation
stiff
material \$matTag \$arg1 \$arg2 ...

ZeroLengthSection Element:

force
deformation
stiff
section \$arg1 \$arg2...

Truss element:

axialForce
forces
localForce
deformations
section \$arg1 \$arg2...
material \$arg1 \$arg2 ...

The valid args for different sections

Valid args to any section type are: *force* and *deformation*

Fiber Section:

forces

deformations

forceAndDeformation

fiber \$fiberNum \$matArg1 \$matArg2 ...

fiber \$yLoc \$zLoc \$matTag \$matArg1 \$matArg2 ...

The valid args for different materials

Valid args to any material are: *strain*, *stress*, and *tangent*

Fatigue Material:

stressStrain

damage

Examples

```

recorder Element <-file $fileName> <-time> <-ele $tg1 $tg2 ...> $arg1 $arg2 ...
                <-xml $fileName>           <-eleRange $tgS $tgE>
                <-binary $fileName>        <-region $rTag>
                <-tcp $inetAddr>
    
```

Force-based beam-column element with fiber sections:

Element forces in global coordinate system:

Force BCE:

```

recorder Element -file ele1force.out -ele 1 force
    
```

```

force
globalForce
localForce
basicForce
    
```

Sectional deformation (axial strain and curvature):

```

recorder Element -file ele1sect1def.out -ele 1 section
    
```

```

section $secTag $arg1 $arg2
1 deformations
basicDeformation
plasticDeformation
inflectionPoint
    
```

Stress in a fiber at a specific location:

```

recorder Element -file ele1sect1fiber00.out -ele 1 section 1 fiber 0. 0. 1 stress
fiber $fiberNum $matArg1 $matArg2 fiber $fiberNum $matArg1 $matArg2 ...
fiber $yLoc $zLoc $matTag $matArg1 $matArg2 fiber $yLoc $zLoc $matTag $matArg1 $matArg2
    
```

Fiber Section:

```

tangentDir
integrationPoints
integrationWeights
    
```

[page](#)[discussion](#)[view source](#)[history](#)

OpenSees

Eigen analysis of a two-storey one-bay frame

Example Provided by: [Vesna Terzic, UC Berkeley](#)

This example demonstrates how to perform eigenvalue analysis and plot mode shapes. A two-storey one-bay frame (Example 10.5 from "Dynamic of Structures" book by Professor Anil K. Chopra) is shown in Figure 1. Node and element numbering is given in Figure 2.

navigation

- [OpenSees Home](#)
- [Message Board](#)
- [OpenSees Wiki](#)
- [User Documentation](#)
- [Download Page](#)
- [Source Code](#)

search

toolbox

- [What links here](#)
- [Related changes](#)
- [Special pages](#)
- [Printable version](#)
- [Permanent link](#)




Figure 1




Figure 2

Contents [\[hide\]](#)

- 1 [Instructions on how to run this example](#)
- 2 [Create the model](#)
- 3 [Define recorders](#)
- 4 [Perform eigenvalue analysis](#)
- 5 [Record the eigenvectors](#)
- 6 [Display mode shapes](#)

“puts” command used to print data to the screen

In addition to storing periods into a file we can also print it to the terminal using **puts** command:

puts “\$string”

Example (EigenAnal_twoStoreyFrame.tcl): printing periods on terminal

```
# print periods to terminal  
puts “periods of the frame are: $T”
```

```
OpenSees -- Open System For Earthquake Engineering Simulation  
Pacific Earthquake Engineering Research Center -- 2.3.0  
  
<c> Copyright 1999,2000 The Regents of the University of California  
All Rights Reserved  
<Copyright and Disclaimer @ http://www.berkeley.edu/OpenSees/copyright.html>  
  
OpenSees > source EigenAnal_twoStoreyFrame.tcl  
periods of the frame are: 0.6285387528267521 0.23593885745804652  
OpenSees >
```

Print command

http://opensees.berkeley.edu/wiki/index.php/Print_Command

To print all objects of the domain:

```
print <-file $fileName>
```

To print node information:

```
print <-file $fileName> -node <$node1 $node2 ...>
```

To print element information :

```
print <-file $fileName> -ele <$ele1 $ele2 ...>
```

Example (EigenAnal_twoStoreyFrame.tcl):

```
print -node 3
```

```
OpenSees > print -node 3
Node: 3
  Coordinates : 0 120
  Disps: 0 0 0
  Velocities  : 0 0 0
  commitAccels: 0 0 0
  Mass :
0.259067 0 0
0 0 0
0 0 0

  Rayleigh Factor: alphaM: 0
  Eigenvectors:
0.666844 1.21874
0.00224274 -0.00138942
-0.00599676 -0.00256026
```

Commands That Return Values

[http://opensees.berkeley.edu/wiki/index.php/Misc Commands](http://opensees.berkeley.edu/wiki/index.php/Misc_Commands)

•analyze command

```
set ok [analyze numIter < $\Delta t$ >]
```

•getTime command

```
set currentTime [getTime]
```

•nodeDisp command

```
set disp [nodeDisp $node <$dof>]
```

•nodeVel command

```
set vel [nodeVel $node <$dof>]
```

•nodeAccel command

```
set acc [nodeAccel $node <$dof>]
```

•nodeEigenvector
command

```
set eig [nodeEigenvector $node  
$eigenvector <$dof>]
```

•eleResponse command


```
set resp [eleResponse $eleTag $arg1 $arg2 ...]
```


Example: eigenvectors for translational DOFs

- nodeEigenvector command `set eig [nodeEigenvector $node $eigenvector <$dof>]`

```
# get 2 eigenvectors for nodes 3 and 5
set f11 [nodeEigenvector 3 1 1]
set f21 [nodeEigenvector 5 1 1]
set f12 [nodeEigenvector 3 2 1]
set f22 [nodeEigenvector 5 2 1]

# print them on terminal in a normalized form
puts "eigenvector 1: [list [expr {$f11/$f21}] [expr {$f21/$f21}]]"
puts "eigenvector 2: [list [expr {$f12/$f22}] [expr {$f22/$f22}]]"
```




```
C:\Documents and Settings\vesna\My Documents\Wahin\OpenSees\OpenSees Days 2011\Rec... - [x]
OpenSees -- Open System For Earthquake Engineering Simulation
Pacific Earthquake Engineering Research Center -- 2.3.0

(c) Copyright 1999,2000 The Regents of the University of California
All Rights Reserved
(Copyright and Disclaimer @ http://www.berkeley.edu/OpenSees/copyright.html)

OpenSees > source EigenAnal_twoStoreyFrame.tcl
eigenvector 1: 0.38690042563895255 1.0
eigenvector 2: -1.29232217611099904 1.0
OpenSees > _
```

Display command




```
recorder display $windowTitle $xLoc $yLoc $xPixels $yPixels  
prp $x $y $z  
vup $x_v $y_v $z_v  
vpn $x_n $y_n $z_n  
viewWindow $x_{prp,n} $x_{prp,p} $y_{prp,n} $y_{prp,p}  
display $arg1 $arg2 $arg3
```



Display command: example

```

set h 120
recorder display "Mode Shape 1" 10 10 500 500
prp $h $h 1
vup 0 1 0
vpn 0 0 1
viewWindow -200 200 -200 200
display -1 5 20
    
```



Procedures for graphical visualization

- For 2D and 3D frame structures the procedures for graphical visualization can be downloaded from the example manual
- For 2D frames:
[http://opensees.berkeley.edu/wiki/index.php/
OpenSees_Example_6._generic_2D_Frame,_N-story_N-bay,_Reinforced-Concrete_Section_%26_Steel_W-Section](http://opensees.berkeley.edu/wiki/index.php/OpenSees_Example_6._generic_2D_Frame,_N-story_N-bay,_Reinforced-Concrete_Section_%26_Steel_W-Section)
- For 3D frames:
[http://opensees.berkeley.edu/wiki/index.php/
OpenSees_Example_7._3D_Frame,_3-story_3-bayX_3-bayZ,_Reinforced-Concrete_Section_%26_Steel_W-Section](http://opensees.berkeley.edu/wiki/index.php/OpenSees_Example_7._3D_Frame,_3-story_3-bayX_3-bayZ,_Reinforced-Concrete_Section_%26_Steel_W-Section)
- The proc files are: DisplayPlane.tcl, DisplayModel2D.tcl, DisplayModel3D.tcl

Summary

- Use RECORDER command to monitor response quantities of interest during analysis
- Use PUTS command to:
 - create output files of quantities that RECORDER does not support
 - print data onto the screen
- Use PRINT command to get information about all or some objects of the domain
- Use commands that return values (e.g. nodeDisp) to:
 - check your model
 - change parameters of the model or analysis in the course of analysis
- Use “recorder display” command or OpenSees procedures for creating graphical images of OpenSees models

Questions?